




1mm STYRENE SHEET




2mm STYRENE  
SANDED



1mm STYRENE



4mm STYRENE – SANDED  
2 LAYERS 2mm



NUMBER DISK  
1mm STYRENE





1mm STYRENE




0.5mm STYRENE

2No. HINGES




HEX SHAPED RIM BOLTS  
1mm STYRENE



APPLY 0.5mm THICK  
RIM AROUND SMOKEBOX

2mm STYRENE PACKERS TO REAR OF  
SMOKEBOX FRONT  
– TIGHT TO INSIDE OF BOILER PIPE



REAR PACKERS—ANOTHER WAY!

# SMOKEBOX FRONT

