



CORNICE – 0.5 mm STYRENE STRIP

Optional :

Corners to windows and doors are slightly rounded on prototype 1880s cab.
Drill corners with 3mm drill bit to simulate radius.
Applicable to this outer layer only as shown.
Actual radius appears to vary between cabs from different locos



SIDE
1MM STYRENE



1880s REBUILT MASON CAB
CAB WALLS – OUTER LAYER –1

